



GRAIN PROTECTION CHECKLIST

Questions? Contact us:

1-844 Real Grain

info@realmccoy.ag

✓	When	What	How	Why
<input type="checkbox"/>	14-30 days before harvest	Kill all weeds & grass around bins.	Use a herbicide labeled for use around bins.	Removes a breeding ground for bugs.
<input type="checkbox"/>	14-30 days before harvest	Clean out bins including under the floors & spray with Diacon Plus & PBO-8.	Mix 1 oz of Diacon Plus, 1.5 oz of PBO-8 with 1 gallon of water.	Very important to remove old crop and insects there feeding and laying eggs.
<input type="checkbox"/>	14-30 days before harvest	Clean harvest equipment, augers and belts & spray with Diacon Plus & PBO-8.	Mix 1 oz of Diacon Plus, 1.5 oz of PBO-8 with 1 gallon of water	Eliminate potential infestations from old insect infested grain.
<input type="checkbox"/>	Harvest	Spray Diacon Plus/PBO-8 mixture on grain as it enters storage.	Apply the label prescribed mixture of Diacon Plus, PBO-8 & 5 gallons of water per 1,000 bushels.	Spraying grain will kill live insects and keep them from creating an infestation for up to 12 months.
<input type="checkbox"/>	Harvest	Take samples of treated grains and store in mason jars	Take samples from multiple loads entering the bin and place a paper towel on top with a rubber band. Label the jars so you know the date and bin.	Monitoring the grain this way gives you an alarm that can let you get ahead of any trouble.
<input type="checkbox"/>	Harvest & every 14 days after harvest (Reset after rain)	Treat the outside of the bin with Diacon Plus, PBO-8, & Water 6 feet up and out.	Mix 1 oz of Diacon Plus, 1.5 oz of PBO-8 with 1 gallon of water.	Create a barrier to keep those insects from migrating into the bins.

WARNING: Each of these steps is important in creating an environment that is challenging for bugs to survive and while spraying the grain is very important, failure to implement an Integrated Pest Management Plan as designed can lead to insects overwhelming a single treatment.